

# Image Trans Opaque

## Opaque Transfer Paper for Dark Fabrics INFORMATION & INSTRUCTIONS

Last Updated: December 2002

  
PAROPY  
IMAGE TRANS



### Warning

**Do NOT run Opaque through your Copier or Printer.**

### About Opaque

The IMAGETRANS Opaque Transfer System is a thin white fabric patch used to transfer images onto dark fabric. Image your CL or Inkjet transfer paper, press the transfer paper to the Opaque, press the Opaque to the garment.

### Heat Press Set-Up

- Set temperature to 375°F (190°C).
- Set pressure to High, Maximum Pressure.

### Bonding Imaged Transfer to Opaque

- Place Opaque sheet on the heat press, Fabric Side Up.
- Position Imaged CL or Inkjet Transfer Paper imaged side down on top of opaque sheet.
- Press for 5-10 seconds. Remove from press.
- Peel Transfer Paper away while warm.
- Trim as Required.

### Pressing Opaque to Garment

- Place Garment on heat press.
- Remove Backing Paper from the Opaque sheet, exposing adhesive.
- Position Opaque on garment, sticky side down. Cover with Silicon sheet.
- Press for 20-30 seconds with Maximum Pressure.
- Open heat press and remove silicon sheet.

### Washing Instructions

- Machine wash on gentle cycle or hand wash in cool water.
- Do not use Bleach or Fabric Softener (including Bounce Dryer Sheets).
- Detergents with Bleach additives are not recommended.
- Air dry in dryer or hang dry.
- Do not Dry Clean.

**Technical Support # 416-368-1141/1-888-899-6955/Fax# 416-368-1141**

**E-Mail: [info@tropicalgraphics.ca](mailto:info@tropicalgraphics.ca) Web Site: [www.tropicalgraphics.ca](http://www.tropicalgraphics.ca)**