

# Water Slide (WT)

## Wet Release Transfer Paper INFORMATION & INSTRUCTIONS



Last Updated: September 2004

### Recommended Applications

Candles, Glass, Metal, Wood and Soap

### Recommended for use with

Color Laser Copiers and Printers, Black and White Copiers, Thermal Printers, Oil based Felt Pens or Acrylic Color Paints

### What you will need

- Item to be imaged ie: candle, glass etc.
- Imaged WT Transfer Paper
- Bowl large enough to dip chosen object into
- Liquid dish soap
- Plastic— either plastic wrap or plastic bag
- 1 sheet of plain bond paper

### Note

This application is for decorative use only. Candles can be burned do not wash decorative decal items.

### Imaging IMAGETRANS — WT

- ? If using a Color Copier, Black and White Copier or Thermal Printer:
  - Place WT Paper in bypass tray, positioned to image onto Glossy side
  - Copy/Print in plain paper/standard copy mode. Do NOT use mirror image function.
- ? If Using Oil based felt pens or Acrylic color paints:
  - Draw on Glossy side of WT transfer Paper. Let image dry completely before proceeding.

### Application Instructions

- Trim imaged WT as close as possible to image without cutting into image, using either scissors or an exacto knife.
  - Fill suitable size bowl with warm water and add about 5%-10% liquid dish soap to bowl of water.
  - Wet the item to be imaged in the bowl of water and set to one side.
  - Place imaged WT in bowl of soapy water for 5-10 seconds.
  - Put wet WT on plastic, image face down, and cover with plain sheet of paper to take off excess water.
  - Remove plain paper.
  - Gently remove paper backing from WT Transfer Paper.
  - Pick up plastic with imaged decal/film laying on top and place on candle, glass or other item.
  - Gently remove plastic.
  - With sponge or finger correct position of decal and take out any air bubbles.
  - Let dry for at least 1 hour before handling.
- NOTE: For extra durability on candles we suggest using a glue stick to help adhere the WT Transfer Paper or heating the candle with a blow dryer to soften the wax before applying the transfer.

**Technical Support # 416-368-1141/1-888-899-6955/Fax# 416-368-1141**

**E-Mail: [info@tropicalgraphics.ca](mailto:info@tropicalgraphics.ca) Web Site: [www.tropicalgraphics.ca](http://www.tropicalgraphics.ca)**